

Possum Combi 4 Part Number 034-989 Quick Start Guide V1






Front View

Rear View

Number	Function / Connector
1	Activity Indicator LED's
2	Inbuilt Resistive Switches / User Button's
3	1/4" UNC Mounting point and anti-rotation lug
4	Wireless Charging Area
5	Charging Indicator LED
6	Speaker
7	Setup / Change Mode Button
8	Setup / Change Mode Indicator LED
9	Recessed On/Off Push Button
10	Charging Socket for Mini Coaxial PSU
11	3.5mm Jack Switch Input
12	Switch Input Mode Adjuster for 1 or 2 Switches



8 Farmbrough Close Stocklake Park Industrial Estate Aylesbury, Bucks, HP20 1DQ 01296 461000 info@possum.co.uk



Dimensions and Specifications		
Width	73mm	
Height	116mm	
Depth	30mm	
Weight	150g	
Radio Frequencies	Tx & Rx 869.2Mhz	
(RF)	Bluetooth 5 LE 2.4 GHz	



Please read the User Guide before using the product.

The User manual includes detailed usage instructions including all safety information! This can be found at the QR code link shown below, on the product label or by contacting Possum Ltd


This Quick Start Guide should only be used as a reference.





CHARGING THE COMBI 4


The Possum Combi 4 Box is designed to charge and operate from a single co-axial power supply unit supplied by Possum Ltd part number 034-982



Plug charger into here.

TURNING ON YOUR COMBI 4

- 1. Before switching on your Combi 4 it is advisable to plug in the Possum Mini Coaxial PSU to charge the battery
- 2. After a couple of minutes use a sim card eject tool or similar to push into the power hole on the side of the device.





Use tool here.






POWER INDICATION

On the side of the Combi 4 Box is a small LED the Charging Indicator LED which displays the charging status of the Combi 4 Box.

On the Front of the Combi 4 Box is a small LED the Activity Indicator LED which displays a green LED when the Combi 4 Box has been activated.



Charging Indicator LED		
Colour	Status	
Amber	Charging	
Green	Full	